



| R14 x hfe must keep transistors fully conducting state
at max operating current

H01
H02
H03
H08

Insulated PSU prototype

Baxandall / Royer converter

OH2NLT

DRAWING No.

Rev. B 06.03.2020

Drawn

05.03.2020

JNi

Appr.

Page 1